HIT-FLON®

100 ml

Engine coating 18,500 miles • 10 l oil volume Fuel saving up to 200 l

Lower fuel consumption	¥ 25 %
Lower oil consumption	¥ 80%
Better emission values	¥ 30 %
Better performance	▲ 15 %
Quieter running	∀ 10%
Reduced engine temperature	∀ 10%
Less wear	▼ 54%
Emergency lubrication	▼ 100 %
▲∀ = up to (theory)	

HUTH INDUSTRIE TECHNIK

Made in Germany • www.hit-flon.com

Operating Instructions

To be strictly followed.

- Suitable for all gas-powered and diesel engines with a minimum 15,500 miles – no new vehicles.
- Shake the bottle thoroughly before opening it PTFE particles are heavier than oil.
- Engine must be warm to the touch; therefore, run it for a short period of time before filling.
- Pour the entire bottle into the oil container;
 100 ml is good for 10 litres of oil. Always remove lower part of the cap with the cap from the bottle.
- Subsequently, run the engine for at least 16 miles.
- Important: coating takes place during the next 600 miles.
- After adding HIT-FLON® to the oil, change oil only after 600 miles.
- Coating remains up to 18,500 miles, also after an oil change.

HIT-FLON®

200 ml

White cap

41,000 miles • 25-40 l oil volume Diesel saving up to 1,000 l

Black cap

41,000 miles • 10-25 l oil volume Diesel saving up to 750 l

Lower fuel consumption	▼ 25 %
	¥ 00 0/
Lower oil consumption	▼ 80 %
Better emission values	∀ 30%
Detter emission values	V 30 /0
Better performance	▲ 15%
Quietes supping	∀ 10 %
Quieter running	V 10 %
Reduced engine temperature	▼ 10 %
Less wear	▼ 54 %
For any or the body of the state of	¥ 4000/
Emergency lubrication	▼ 100 %

 $\blacktriangle \forall$ = up to (theory)

Engine coating

Operating Instructions

To be strictly followed.

- Suitable for all diesel engines with a minimum 62,000 miles – no new vehicles.
- Shake the bottle thoroughly before opening it PTFE particles are heavier than oil.
- Engine must be warm to the touch; therefore, run it for a short period of time before filling.
- Pour the entire bottle into the oil container. Always remove lower part of the cap with the cap from the bottle.
- Subsequently, run the engine for at least 37 miles.
- Important: coating takes place during the next 1,250 miles.
- After adding HIT-FLON® to the oil, change oil only after 1,250 miles.
- Coating remains up to 41,000 miles, also after an oil change.